

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7





FIG. 8



$$P_A, P_B : \text{PULSE WIDTH} \begin{cases} P_{B'} = P_B \times 1.3 & f_1 (i=1 \sim 7) : \text{FIELD} \\ P_{A'} = P_A \times 0.7 & D_1, D_2 : \text{GRADATION} \end{cases}$$

FIG. 9




FIG. 10




FIG. 11




FIG.12




FIG.13




FIG. 14






FIG. 15




EXAMPLES


BASIC 12 GRADATIONS




BASIC 12 GRADATIONS + 1 GRADATIONS




BASIC 12 GRADATIONS + 2 GRADATIONS




BASIC 12 GRADATIONS + 3 GRADATIONS




BASIC 12 GRADATIONS + 4 GRADATIONS




BASIC 12 GRADATIONS + 5 GRADATIONS



BASIC 12 GRADATIONS + 6 GRADATIONS



BASIC 12 GRADATIONS + 7 GRADATIONS



BASIC 13 GRADATIONS




FIG.16




FIG.17




FIG.18




FIG.19




FIG.20




FIG. 21




FIG. 22




FIG.23

200T/0" T442900T




FIG.24




FIG.25